

## STORAGE GUIDELINES FOR TROPICAL PLUS COMMANDER 290L & 340L AND COLTRI 235L

It is recommended that the compressor is operated at least twice a month for at least one (1) hour each time. The guidelines below are to be followed if the compressor unit will not be used for a long period of time e.g. not used for more than 2 weeks.

Should the compressor not be used, it must be stored in a dry sheltered area at an ambient temperature between 5 °C and 45 °C

## NOT OPERATING THE MACHINE FOR A LONG PERIOD:

- 1. Remove the filter cartridge and replace back the filter cartridge screw cap, run the compressor for 4-5 minutes with the filling valves and condensate drain valves open (not actually filling tanks). This is to flush out all the residual condensate.
- 2. Stop the compressor and remove intake filter cartridge. Re-start the compressor and spray a few drops of compressor oil (approx. 10 ccl / 0.6 cu. in) into the air intake opening so that a light film of lubricant is aspirated and penetrates the interior of the compressor. Do not warm up too much, run the compressor for no more than 2 minutes so you do not burn off the oil.
- 3. Stop the compressor and re-fit the air intake filter. Clean the external parts and eliminated any moisture, salt or oil deposit. Put a dust cap on the intake filter port.
- 4. Switch off the machine main switch and remove the plug from the main power socket (if any).
- 5. Protect the compressor from dust and water by storing it in clean, dry place.
- 6. Lightly close the condensate drain valves and cover with masking tape to prevent anything from entering or blocking the system. Cover the filling whip valves with masking tape.

## **REACTIVATING THE MACHINE:**

- 1. Remove the dust cap on the intake filter port.
- 2. Check oil level of the compressor.
- 3. If the machine did not run for a period of 1 year replace the compressor oil and replace the filter cartridges with new one.
- 4. Remove the filter cartridge and replace back the filter cartridge screw cap.
- 5. Remove the Air intake filter.
- 6. Turn ON the main power switch.
- 7. Run the compressor by turning ON the green button of the magnetic switch; spray a few drops of compressor oil into the air intake opening (approx. 10 ccl / 0.6 cu. in). This will help to lubricate the head valves and prevent valve seizure (for compressor stocked for several weeks / months without running, valves may develop a rusty patina on spring and plates which may cause malfunction.
- 8. Run the compressor for approximately 20 minutes so the oil will circulate in the system, with the condensate drain valves and filling valves open.
- 9. After 20 minutes replace back the air intake filter and filter cartridge.
- 10. With the filling valves closed, run the compressor until final pressure reaches 225 BAR and final safety valve blows.
- 11. Check the inter-stage safety relief valves for leakage.
- 12. Stop the compressor when running properly; the compressor is now ready for operation.